

PMP2WSSSBOZ – 4" Windscreen Shroud Assembly

Assembly Order

1. 4" mPower Light (Sold Separately)
2. 4" Heatsink (Sold Separately)
3. Deflector
4. 3M VHB Dual-Lock Mounting Tape
5. Face Gasket
6. Windscreen Shroud
7. Mounting Nuts (Sold Separately)

Installation

1. Insert the Light through the heatsink. The wires should exit through one of the following:
  - a. Top write Exit (orient heatsink with wire exit up)
  - b. Housing centre Knock out or drill hole through shroud for desired wire exit
  - c. Bottom exit (orient heatsink with wire exit up)
2. Wipe the shroud flange and the glass surface with an Alcohol Wipe or a mix of isopropyl alcohol and water (50:50)
3. Once dry stick the 3m Dual lock tape and foam face gasket to the shroud (some trimming may be required)
4. Adjust the mPower light so that the face is perpendicular to the ground and tighten the nuts (DO NOT OVER TIGHTEN)
5. Remove 3m dual lock backing and stick to glass. Apply firm pressure for 30 seconds to ensure a good bond.

